



BURLINGHAM
SPORTS

JUMP FOOT ATTACHMENT INSTRUCTIONS

Tools Needed: ½” socket wrench.

To attach the foot to the Jump Standards

- 1) Lay the standard down on its side.
- 2) Push the foot on to the bottom of the post (leg) snugly.
- 3) Insert the bolt through the washer then through the hole at the bottom of the foot.
- 4) Start threading the bolt into the threads on the bottom of the post (leg)
- 5) Using a ½” socket wrench tighten the bolt. Tighten snug, but do not over tighten.

Note: The Feet are equipped with a screw plug.

For added stability in High Wind areas. Prior to assembly of foot to jump. We recommend that you add sand or dirt to Jump Feet utilizing the plug on the bottom of each Jump Foot.