



BURLINGHAM SPORTS

ATTACHMENT INSTRUCTIONS

* WOOD SCREWS

Used when the product is thick enough that the point of the screw does not poke through to the inside of the product. (Such as Double Wall products. Example: Deluxe Trunks)

- 1) Locate position of plate and with awl or sharp object mark starting point for screw. Do this with only one hole initially
- 2) Using a hand screwdriver, drive screw in by hand right into the plastic.
- 3) With a sharp eye, make sure the plate is straight and mark the second hole.
- 4) Then screw in the second screw and make sure both screws are snug.

* POP RIVETRS

Used on single thick wall products such as the Pony Sport and Small Sport.

- 1) Mark location of plate and mark one hole.
- 2) Using a drill bit, drill through the plastic making a hole
- 3) Using a hammer and something to strike against, such as metal block or hard piece of wood. Insert the male portion of the pop rivet through the hole from the back of the product. Place the plate over the pop rivet. While holding the support metal block or wood block on the back side put the cap of the pop rivet over the male piece poking through the nameplate. Strike the cap with the hammer while holding the back support block. This is an easier operation using a helper.
- 4) With a sharp eye, make sure the plate is straight and mark the second hole.
- 5) Repeat step 3) with the second hole.