



**BURLINGHAM
SPORTS**

INSTRUCTIONS FOR WHEEL ASSEMBLY INSTALLATION

Tools Needed:

Hammer, Philips Screw Driver, 7/16" Wrench or Socket, Drill Motor,
1/4" and 3/8" Drill Bits

- 1) Your "*Pony Sport*" tack trunk may have already come with the holes drilled for the axle and the two legs. If so, skip to step (4) of these instructions.
- 2) Facing the front of the trunk the wheels will be installed on your right. There is a drill mark on the trunk 1/2" up from the bottom and 1" in from the side. This drill marking is both on the front and the back of the trunk on the right end. Using the 3/8" drill bit, drill the two axle holes.
- 3) On the bottom of the trunk on the opposite side from the wheels, there are four drill marking points, two for each leg. Using the 1/4" drill bit, drill the four holes through the bottom of the trunk from the outside, using the drill marking points as your location guide.
- 4) One end of the axle is capped. Install one wheel on the axle against the capped end.
- 5) Slide the axle through the two axle holes on the right end of the trunk.
- 6) Once you are through the trunk install the second wheel and attach the cap using a hammer to strike the cap on to the axle. It is best to put the trunk on its side to use the ground or hard surface as a base for the axle to rest against for striking.
- 7) Using the screws provided attach the two legs to the outside of the trunk. The screws are installed from the inside of the trunk through the holes in the bottom of the trunk, through the holes in the legs and capped with the nuts provided. Tighten the screws and nuts firmly to assure the legs are on tight.